

# **Bluff City**

Series

Bluff City

<u>Product</u> Pendant - 8 inch

<u>Dimensions</u> Dia 8in/21cm x H 10in/25cm

Weight 3lb/1.3kg Materials Steel

<u>Finishes</u> Red/blue, white/black

Pendant - 8 inch

Suspension 8-foot cord

Canopy 5-inch round in white

Certifications UL, cUL (120V) CE, CB (240V) UL, cUL, CE, CB (Universal) 120V Incandescent Illumination

Socket: E26 Bulb: 60 Watt G40 Wattage: 60 Watts Lumens: 550 Lumens

Color Temperature: 2700 Kelvin

Dimming: Triac or ELV

240V Incandescent Illumination

Socket: E27 Bulb: 60 Watt G40 Wattage: 60 Watts Lumens: 550 Lumens

Color Temperature: 2700 Kelvin

Dimming: Triac or ELV

LED Alternative Socket: E26/E27


Bulb: 6 Watt G40 frosted LED

Wattage: 6 Watts Lumens: 480 Lumens

Color Temperature: 2700 Kelvin

Dimming: ELV

#### **CONTENTS**



#### SAFETY INFORMATION

Only one light bulb per socket.

Only suitable for direct mounting on non-combustible surfaces.

Under no circumstances can Bluff City Pendants be mounted on normally flammable surfaces. Suitable for dry, indoor use only.

Maximum ambient temperature: 25° C


If the external flexible cable or cord of this luminare is damaged, it shall be exclusively replaced by Roll & Hill or Roll & Hill's service agent or a similarly qualified person in order to avoid hazard.

# Roll & Hill


### **CEILING INSTALLATION**

Note: Please contact a licensed electrician. Note: Do not use bulbs that exceed 60 watts.

1. Install crossbar (A) to junction box (B) using #8-32 screws (C). It is recommended to pull the main wires out so they are accessible while making the main connection later. Once secure, screw the nipple (D) into crossbar.



- 2. Cut the electrical cable to desired length and feed through the bushing in the ceiling canopy (E) and the nipple.
- 3. Tie a knot in the electrical cable above the crossbar and crimp the C shaped strain relief (F) just below the knot.
- 4. Strip wires and make connections to the leads in the ceiling using provided wire nuts (G). Attach the green ground wire to the crossbar with ground screw.
- 5. Tuck the connected wires into the junction box. Raise the canopy and knurled nut to thread onto nipple, tightening the canopy flush to the ceiling.
- 6. Make sure fixture is powered off and screw the bulb into the socket.




### **CEILING INSTALLATION continued**


## For Bluff City 8 inch only:


6. Make sure fixture is powered off and screw the bulb into the socket.

## For Bluff City 14 inch only:

6. Loosen the cover nut (H) above the socket cap (I) by screwing counter-clockwise. This raises the socket cap to allow room to insert the globe (J). Tilt the globe so that it fits around the internal fitter (K) and hangs underneath the socket cap. Gently tighten the cover nut to hold the globe in place.







# **Bluff City**

Series Bluff City

Product Pendant - 14 inch

<u>Dimensions</u> Dia 14in/36cm x H 13in/32cm

Weight 4lb/1.8kg

# Pendant - 14 inch

<u>Materials</u> Steel, aluminum, glass

Finishes
Mint/red, cream/brown, white/brass

Suspension 8-foot cord

<u>Canopy</u> 5-inch round in white

Certifications UL, cUL (120V) CE, CB (240V) UL, cUL, CE, CB (Universal) 120V Incandescent Illumination

Socket: E26 Bulb: 60 Watt A19 Wattage: 60 Watts Lumens: 550 Lumens

Color Temperature: 2700 Kelvin

Dimming: Triac or ELV

240V Incandescent Illumination

Socket: E27 Bulb: 60 Watt A19 Wattage: 60 Watts Lumens: 550 Lumens

Color Temperature: 2700 Kelvin

Dimming: Triac or ELV

LED Alternative Socket: E26/E27


Bulb: 6 Watt A19 frosted LED

Wattage: 6 Watts Lumens: 480 Lumens

Color Temperature: 2700 Kelvin

Dimming: ELV

### **CONTENTS**



#### SAFETY INFORMATION

Only one light bulb per socket.

Only suitable for direct mounting on non-combustible surfaces.

Under no circumstances can Bluff City Pendants be mounted on normally flammable surfaces. Suitable for dry, indoor use only.

Maximum ambient temperature: 25° C


If the external flexible cable or cord of this luminare is damaged, it shall be exclusively replaced by Roll & Hill or Roll & Hill's service agent or a similarly qualified person in order to avoid hazard.

# Roll & Hill


### **CEILING INSTALLATION**

Note: Please contact a licensed electrician. Note: Do not use bulbs that exceed 60 watts.

1. Install crossbar (A) to junction box (B) using #8-32 screws (C). It is recommended to pull the main wires out so they are accessible while making the main connection later. Once secure, screw the nipple (D) into crossbar.



- 2. Cut the electrical cable to desired length and feed through the bushing in the ceiling canopy (E) and the nipple.
- 3. Tie a knot in the electrical cable above the crossbar and crimp the C shaped strain relief (F) just below the knot.
- 4. Strip wires and make connections to the leads in the ceiling using provided wire nuts (G). Attach the green ground wire to the crossbar with ground screw.
- 5. Tuck the connected wires into the junction box. Raise the canopy and knurled nut to thread onto nipple, tightening the canopy flush to the ceiling.
- 6. Make sure fixture is powered off and screw the bulb into the socket.



### **CEILING INSTALLATION continued**

## For Bluff City 8 inch only:

6. Make sure fixture is powered off and screw the bulb into the socket.

## For Bluff City 14 inch only:

6. Loosen the cover nut (H) above the socket cap (I) by screwing counter-clockwise. This raises the socket cap to allow room to insert the globe (J). Tilt the globe so that it fits around the internal fitter (K) and hangs underneath the socket cap. Gently tighten the cover nut to hold the globe in place.

